

StateMix

Flex Cell Station



Flex Cell Station



Touch Screen Computer

This computer acts as the operator interface and is connected to all the injectors and also to the digital scale. It can maintain multiple recipes and store pour information for future quality control printouts. After every pour the computer will display and if required print the amount of material requested from the operator as well the amount that was dispensed.



Computer controlled Injector valves

Each injector is specially designed for dispensing a wide range of viscosities and flow rate, which make the Flex Cell a very universal dispenser that can have as many as 6 separately controlled injectors. All injectors and lines are heated, this allows you to leave material in the lines when shutting down the unit without flushing the line, and re-melting material when turning the unit on.



Digital Scale

The digital scale is located under the injector assembly and is connected to the main computer. It sends real time weight information to the main computer via a digital communication port as the material is being dispensed into the pail.

StateMix

1390 Church Ave
Winnipeg, Manitoba
R2X 1G4, Canada
Ph: (204) 697-2586
Fax: (204) 697-2592
www.statemix.com

STATE MIX BUSINESS PARTNER



MITEX GmbH · Ludenberger Str. 36-40 · D-40699 Erkrath
Tel.: +49 (0)211 90006-0 · Fax: +49 (0)211 246118
info@mitex.de · www.mitex.de · www.vortex-mixer.de